



Hydraulik:

**833123U**

IBN-Code:

**209**

# Startup guide: 209

## Service > settings > system settings

Integration	=	Sp. Tank
Mixing circ 1	=	No
Mixing circ 2	=	No
Mixing circ 3	=	No
2hg1 type	=	El. rod
2hg1 fct.	=	HW a SW
2hg2 type	=	No
2hg2 fct.	=	No
2hg3 type	=	No
2hg3 fct.	=	No
Service water 2	=	CP
Service water 3	=	with CP
Service water 5	=	wo. HSP
Pump opt.	=	Yes

## Important extended information:

- 
- 
- 
- 
- 
- 
- 
- 
- 

### Advice:

The red marked parameters concern the comfort board!

They are only shown in the display if the comfort board is installed!

Only items from the menu "system settings" of the heating and heat pump controller are listed here that are important for the hydraulic integration!

