



Hydraulik:

833439Ua

IBN-Code:

228

Startup guide: 228

Service > settings > system settings

Integration	=	Sep. tank
Mixing circ 1	=	HW+Cool
Mixing circ 2	=	Cool
Mixing circ 3	=	No
2hg1 type	=	El. rod
2hg1 fct.	=	Heating
2hg2 type	=	El. rod
2hg2 fct.	=	SW
2hg3 type	=	No
2hg3 fct.	=	No
Service water 2	=	CP
Service water 3	=	with CP
Service water 5	=	wo. HSP
Pump opt.	=	Yes

Important extended information:

- Comfort board function necessary
-
-
-
-
-
-
-

Advice:

The red marked parameters concern the comfort board!

They are only shown in the display if the comfort board is installed!

Only items from the menu "system settings" of the heating and heat pump controller are listed here that are important for the hydraulic integration!

